

DENON

Language

Control Dock for iPod® ASD-11R

- Enjoy photos and videos from your iPod
- Enjoy music from your iPod with high quality sound
- Display iPod information on your TV
- Recharge your iPod

Black

White



- * iPod not included.
- * Screen image simulated
- * iPod is a trademark of Apple Inc. registered in the U.S.
- * Only the black version is available in the US and Canada.

Features


Enjoy photos and videos from your iPod

The ASD-11R lets you connect your iPod to a Denon component with Dock Control and play the photos and videos stored in your iPod.




Display iPod information on your TV

You can monitor iPod text information, such as menus and track names, on a TV screen, or the front display of a Denon component with Dock Control.



ASD-11R connection ports



Recharge your iPod

The battery is charged automatically when the

Specifications

Enjoy music from your iPod with high quality sound

The ASD-11R allows you to connect your iPod to a Denon component with Dock Control and play the music stored in your iPod without losing sound quality.

iPod is inserted into the ASD-11R.




Recharge

Dimensions: 104 (W) x 28.5 (H) x 76.5 (D) mm / 4-3/32" x 1-1/8" x 3"

Weight: 220 g / 7.76 oz

Connection ports: Analog audio output x 1, S-Video video output x 1, Control port x 1



* Design and specifications are subject to change without notice.

Supported iPods

The ASD-11R supports iPods equipped with Dock Connector Port (4th generation iPod or later, iPod nano and iPod touch).



iPod

4th generation
20GB



iPod

4th generation
40GB



iPod

4th generation
(color display)
20GB 30GB



iPod

4th generation
(color display)
40GB 60GB



iPod

5th generation
(video)
30GB



iPod

5th generation
(video)
60GB 80GB



iPod mini

1th generation
4GB 6GB



iPod nano

1th generation
1GB 2GB 4GB



iPod nano

2nd generation
(aluminum)
2GB 4GB 8GB



iPod nano

3rd generation
(video)
4GB 8GB



iPod classic

80GB 160GB



iPod touch

8GB 16GB 32GB

[Notes of Caution when using Remote mode with iPod touch](#)

Compliant Models Chart

| Product Name | iPod information *1 | | Region (⇐=Available, including discontinued models) | | | |
|--------------|---------------------|------------------|---|-----------|--------------|-------|
| | Front display | Onscreen display | USA/Canada | Europe/UK | Asia&Pasific | Japan |
| AVP-A1HDCI | ✓ | ✓ | • | | | |
| AVP-A1HD | ✓ | ✓ | | • | • | • |
| AVR-5308CI | ✓ | ✓ | • | | | |
| AVC-A1HD | ✓ | ✓ | | • | • | • |
| AVR-4308CI | ✓ | ✓ | • | | | |
| AVR-4308 | ✓ | ✓ | | • | • | |
| AVR-3808CI | ✓ | ✓ | • | | | |
| AVR-3808 | ✓ | ✓ | | • | • | |
| AVC-3808 | ✓ | ✓ | | | | • |
| AVR-2809CI | ✓ | ✓ | • | | | |
| AVR-2809 | ✓ | ✓ | | • | • | |
| AVC-2809 | ✓ | ✓ | | | | • |
| AVR-2808CI | ✓ | ✓ | • | | | |

| | | | | | | |
|--------------|---|---|---|---|---|---|
| AVR-2808 | ✓ | ✓ | | • | • | |
| AVC-2808 | ✓ | ✓ | | | | • |
| AVR-2807CI | ✓ | ✓ | • | | | |
| AVR-2807 | ✓ | ✓ | | • | • | |
| AVC-2920 | ✓ | ✓ | | | | • |
| AVR-2309CI | ✓ | ✓ | • | | | |
| AVR-2309 | ✓ | ✓ | | • | • | |
| AVR-2308CI | ✓ | ✓ | • | | | |
| AVR-2308 | ✓ | ✓ | | • | • | |
| AVC-2308 | ✓ | ✓ | | | | • |
| AVR-2307CI | ✓ | ✓ | • | | | |
| AVR-2307 | ✓ | ✓ | | • | • | |
| AVC-1930 | ✓ | ✓ | | | | • |
| AVR-1909 | ✓ | ✓ | • | • | • | |
| AVC-1909 | ✓ | ✓ | | | | • |
| AVR-1908 | ✓ | ✓ | • | • | • | |
| AVR-1907 | ✓ | ✓ | • | • | • | |
| AVC-1630 | ✓ | ✓ | | | | • |
| AVR-1709 | ✓ | | • | • | • | |
| AVR-1708 | ✓ | | • | • | • | |
| AVR-1707 | ✓ | | • | • | • | |
| AVR-1609 | ✓ | | • | | | |
| AVR-1509 | ✓ | | | • | • | |
| AVC-1509 | ✓ | | | | | • |
| AVC-1519 | ✓ | | | | • | |
| AVR-1508 | ✓ | | • | • | • | |
| AVC-1508 | ✓ | | | | | • |
| AVR-1507 | ✓ | | • | • | • | |
| AVR-989 | ✓ | ✓ | • | | | |
| AVR-988 | ✓ | ✓ | • | | | |
| AVR-987 | ✓ | ✓ | • | | | |
| AVR-889 | ✓ | ✓ | • | | | |
| AVR-888 | ✓ | ✓ | • | | | |
| AVR-887 | ✓ | ✓ | • | | | |
| AVR-789 | ✓ | ✓ | • | | • | |
| AVR-788 | ✓ | ✓ | • | | | |
| AVR-787 | ✓ | ✓ | • | | | |
| AVR-689 | ✓ | | • | | • | |
| AVR-688 | ✓ | | • | | | |
| AVR-687 | ✓ | | • | | | |
| AVR-589 | ✓ | | • | | • | |
| AVR-588 | ✓ | | • | | | |
| AVR-587 | ✓ | | • | | | |
| AVR-488 | ✓ | | • | | | |
| AVR-487 | ✓ | | • | | | |
| DHT-FS1 | | | | | | • |
| DHT-FS3 | | | • | • | • | |
| DRA-697CI | ✓ | | • | | | |
| DRA-397 | ✓ | | • | | | |
| DRA-297 | ✓ | | • | | | |
| DRA-37 | ✓ | | • | | | |
| DRA-700AE | ✓ | | | • | | |
| DRA-700AEDAB | ✓ | | | • | | |
| DRA-500AE | ✓ | | | • | | |
| PMA-CX3 | ✓ | | | | | • |
| DRA-CX3 | ✓ | | • | • | • | |
| RCD-CX1 | ✓ | | • | • | • | • |
| DRA-F102 | ✓ | | | • | • | • |
| DRA-F102DAB | ✓ | | | • | | |

| | | | | | | |
|------------|---|---|---|---|---|---|
| RCD-M37 | ✓ | | • | • | • | • |
| RCD-M37DAB | ✓ | | | • | | |
| S-302 | ✓ | ✓ | • | • | • | • |
| S-102 | ✓ | ✓ | • | • | • | • |
| S-81 | ✓ | | • | • | • | • |

*1: Basically music information only.

* Please use Remote Mode  when playing videos.

USA | CANADA | GERMANY | FRANCE | UNITED KINGDOM | CHINA | SINGAPORE | HONGKONG | SOUTH KOREA | TAIWAN | JAPAN | DISTRIBUTORS
 Copyright 2008 Denon Brand Company All rights reserved.